


KOLDER 2 D 4 SZ



Instrukcja montażu Assembly instructions



CAUTION
STICKING PINS HOW TO DRAWING
ACHTUNG
DAS FESTHALTEN PINS
HOW TO ZEICHNUNG
UWAGA! WAŻNE!
KOLKI WBIJAĆ JAK NA
PONIŻSZYM RYSUNKU
W KRAWĘDZ ELEMENTU
11.0 mm
UWAGA!
ATTENTION!

No.	Stc.	L	W	T
1	1	1460	390	38
2	1	1384	367	16
3	1	865	390	38
4	1	799	367	16
5	1	799	367	16
6	1	865	390	38
7	1	812	458	16
8	1	812	458	16
9	2	835	487	4
10	1	835	446	4
11	4	461	360	16
12	4	458	200	16
13	2	350	160	16
14	2	373	142	16
15	4	350	160	16
16	4	357	384	4

