








BELLO 5




Narzędzia potrzebne do montażu




UWAGA !!

MONTOWANIE USZKODZONYCH
ELEMENTÓW POWODUJE UTRATĘ
GWARANCJI


nr	D[mm]	S[mm]	G[mm]	Ilość
1	811	405	16	1
2	811	405	16	1
3	1790	405	16	1
4	1790	405	16	1
5	776	405	16	1
6			2,5	2
7	776	380	16	3
8	665	402	16	1
9	665	402	16	1




W przypadku reklamacji proszę o podanie numeru pakowacza znajdującego się na kartonie



P - 4 St.




U - 2 St.



H - 1 St.




F - 12 St.



N - 4 St.
3 x 25 mm




Z - 1 St.




K - 8 St.



L - 8 St.



C2 - 2 St.




D2 - 2 St.




B - 12 St.




E - 90 St.




W - 12 St.



C1 - 2 St.






D1 - 2 St.



G - 8 St.
3,5 x 16 mm

I





IV

