





ANGEL

AWT90




23.3.2018

- D** Montageanleitung
- FR** Notice de montage
- NL** Handleiding voor de montage
- CZ** Montážní návod
- HU** Szerelési útmutató
- TR** Montaj talimatı
- GB** Assembly Instructions
- IT** Istruzioni di montaggio
- PL** Instrukcja montażu
- SK** Návod na montáž
- RO** Instrucțiunile de montaj
- RU** Инструкции по монтажу





20 min.





1






ZD X4 8x32	NC X4 8x38	ZA X1	S L-57mm X1	TB X1	Z X8	TA X1 3x20	ZE X4
A X34	AB X4	C X16	Z X16 6,5x13	ZC X11	SLZ X6	N X11 3x20	X X18
B X16	H X16	RC mini X8	RC mini X8	GLUE X1	PC mini domyk X8	ND X17 3,5x16	



2





7



- | | |
|---------------------------|------------------------|
| B
6x32
x4 | A
8x32
x8 |
| H
6.3x13
x16 | RC mini
x8 |



8

- | |
|-------------------|
| GLUE
x1 |
|-------------------|





9


- | | |
|----------------------------|----------------------------|
| PC mini domyk
x6 | ND
3.5x16
x12 |
|----------------------------|----------------------------|




10




12




13






11





12




14



15





- ND 3.5x16 x1
- Z x1
- TB x1
- Z x8
- TA x1
- ZE x4

