





LINO



LWT114






30.01.2015.







- | | |
|---|-------------------------------------|
| (D) Montageanleitung | (GB) Assembly Instructions |
| (FR) Notice de montage | (IT) Istruzioni di montaggio |
| (NL) Handleiding voor de montage | (PL) Instrukcja montażu |
| (CZ) Montážní návod | (SK) Návod na montáž |
| (HU) Szerelési útmutató | (RO) Instrucțiuni de montaj |
| (TR) Montaj talimatı | (RU) ИНСТРУКЦИЯ ПО МОНТАЖУ |







1




2





- P x4
- NA 4x13 x8



11



x2

- ZB x8
- ZF x4


13



x2

- P x4
- NA 4x13 x8
- ZD x8
- NC 4x16 x8

12



- Z x32

14