



PRIMO

PRTV160




8.5.2017

- D** Montageanleitung
- FR** Notice de montage
- NL** Handleiding voor de montage
- CZ** Montážní návod
- HU** Szerelési útmutató
- TR** Montaj talimatı
- GB** Assembly Instructions
- IT** Istruzioni di montaggio
- PL** Instrukcja montażu
- SK** Návod na montáž
- RO** Instrucțiunile de montaj
- RU** Инструкции по монтажу





20 min.


1




O X2 	ND 3.5x18 X12 	ZG X3 	YD 7x50 X3 	WB X1 	TB X1 	TA X1 	V 3x13 X4 	ZF X1
R X4 	H2 6.3x30 X8 	PP X4 	HD X8 	NGD X1 	NA 4x13 X9 	P X4 	Z X4 	
B X24 	A 6x32 X26 	C X24 	Z X24 	N 3x20 X2 	X X5 	W3 X2 	M M4x22 X4 	




2




3



5





4





6



7






5






8








10



11



M M4x22 X2	W3 X2
NA 4x13 X8	P X4



TB X1	TA X1	NA 4x13 X1	Z X4	V 3x13 X4	ND 3.5x16 X6	ZF X1
-----------------	-----------------	-------------------------	----------------	------------------------	---------------------------	-----------------