





TENUS BIURKO

Instrukcja montażu
Assembly instructions









22	A	22	B	22	C	30	D	4	E	24	I	4	J	2	K	2	L	2	N	2	Z	2	Y
----	---	----	---	----	---	----	---	---	---	----	---	---	---	---	---	---	---	---	---	---	---	---	---



UWAGA! WAŻNE!
KOŁKI WBIJAĆ JAK NA PONIŻSZYM
RYS. W KRAWĘDZ ELEMENTU!

UWAGA:
ATTENTION:



No	Stc	L	W	T
1	1	730	440	16
2	1	604	300	16
3	1	730	440	16
4	1	318	60	16
5	1	318	440	16
6	1	670	350	16
7	1	730	440	16
8	1	1000	500	22
9	1	318	440	16
10	1	580	300	16
11	1	410	110	16
12	1	261	92	16
13	1	410	110	16
14	1	417	276	3
15	1	346	150	16
16	1	514	346	16