





TENUS
R2D-50

Instrukcja montażu
Assembly instructions



No	Stc	L	W	T
1	1	1900	370	16
2	1	468	60	16
3	1	468	370	16
4	2	468	370	16
5	1	1900	370	16
6	1	502	400	22
7	2	1860	248	3
8	3	468	370	16
9	1	1840	120	16
10	1	600	435	16
11	1	600	435	16

	A	20
	B	20
	C	20
	D	20
	H	1
	E	12
	I	8
	J	4
	K	4
	L	4
	Z	2
	Y	



UWAGA! WAŻNE!
KOŁKI WBIJAĆ JAK NA PONIŻSZYM
RYS. W KRAJEDŹ ELEMENTU!
ATTENTION:

